

PHILIPS

FC9334, FC9333,
FC9332, FC9331,
FC9330





2



3



4



5




6










7












8
































www.philips.com

100% recycled paper
100% papier recyclé

4222.003.4297.1